


# UNI-LIFT 3500 CLT / PLUS

Automotive lift date: 10/2003  
Manual date: 26.10.2003  
Wheel Free Lift Version 0.25RFH CLT



## Operating Instruction and Documentation

Serial number:.....

Retailer address / phone



**Nussbaum**

Nußbaum Hebetechnik GmbH & Co.KG//Korker Straße 24//D-77694 Kehl-Bodersweier//Tel: +49(0)7853/8990  
Fax: +49 (0) 78 53 / 87 87//E-mail: info@nussbaum-lifts.de//http://www.nussbaum-lifts.de

**Table of contents**

Foreword .....	3
Record of installation .....	5
Record of handing over .....	6
1. Introduction .....	7
1.1 Installation and check of the automotive lift .....	7
1.2 Information of Warning .....	7
2. Master document of the automotive lift .....	8
2.1 Lift–manufacturer .....	8
2.2 Application .....	8
2.3 Changes at the construction .....	8
2.4 Displacement of the automotive-lift .....	8
2.5 Declaration of conformity .....	9
3. Technical information .....	10
3.1 Technical ratings .....	10
3.2 Security devices .....	10
3.3 Datasheet .....	12
4. Safety regulations .....	19
5. Operating instructions .....	19
5.1 Lifting the vehicle .....	20
5.2 Lowering the vehicle .....	20
5.3 Lifting the vehicle with the wheel free lift .....	20
5.4 Lowering the vehicle with the wheel free lift .....	21
5.5 Equalisation of the 2 rails (main lift) .....	21
5.6 Manual equalisation of the lift .....	21
6. Troubleshooting .....	22
6.1 Driving on an obstacle .....	23
6.2 Emergency lowering of the main lift/ wheel free lift .....	24
6.3 Reset the main lift after an emergency lowering .....	29
7. Inspection and Maintenance of Nussbaum lifts .....	30
7.1 Maintenance plan of the lift .....	30
7.2 Cleaning of the automotive lift .....	31
8. Security check .....	32
9. Installation and Initiation .....	32
9.1 Installation of the automotive lift .....	32
9.2 Regulations for the installation .....	33
9.3 Erection and doweling of the lift .....	33
9.4 Initiation .....	34
9.5 Changing the installation place .....	35
First security check before installation .....	38
Regular security check .....	39
Extraordinary security check before initiation .....	47
Manual service operation over the keyboard .....	48
Hydraulic diagram without wheel free lift .....	53
Hydraulic diagram with wheel free lift 0.25 CLT .....	55
Electric diagram without wheel free lift .....	57
Electric diagram with wheel free lift .....	<b>Fehler! Textmarke nicht definiert.</b>

## **Foreword**

Nußbaum-Lifts are a result of long-standing experiences.

The high quality and the superior concept guarantee them reliability, a long lift time and the economic business. To avoid unnecessary damages and dangers, read the operating instruction attentive and observe the contents. Another or the described purpose going out use is not valid when not as agreed. This is valid particularly for climb and go.

***Company Nußbaum is not liable for damages arising from this. The user carries the risk alonely.***

### **For the use belonged:**

- to observe all the notice in the operating instruction and
- the following of the inspection and maintenance work and the prescribed tests.
- The instruction for use have to be observed by all persons working with the lift.
- Especially the chapter "Safety/accident Prevention" has to be observed.
- In addition to the safety remarks of the instructions for use the regulations and instructions being valid at the place of operation have to be considered.

### **Obligations of the operator:**

The operator is obliged to allow only those persons complying to the following requirement to work at the unit

- being well acquainted with the basic regulations concerning labour safety and accident prevention and being trained to operate the unit.
- having read and understood the chapter concerning safety and warning instructions and confirmed that by their signature.

### **Dangers when operating with the lift:**

The Nußbaum-Lifts are designed and built according to technical standard and the approved regulations for technical security. Yet, danger for body and life of the operator may turn up when using the lift inexpertly.

### **The lift must only be operated :**

- for its appropriate use
- in unobjectionable condition concerning technical security.

### **Organising requirements**

- The instructions for use are constantly to be kept at the place of operation being at hand at any time.

- In addition to the instructions for use rules pertaining to other regulations i.e. accident prevention and environmental rules are to be observed and directed.
- Safety- and danger alert operation of personal is occasionally and by observing the instructions for use to be controlled.
- As far as required and ordered by regulations personal protective equipment is to be used
- All safety- and danger-hints at the lift are to be observed!
- Spare parts must comply with technical requirements laid down by the manufacturer. This is only warranted with original parts.  
Consider time intervals given or fixed in instructions for use for repeated tests/inspections.

**Maintenance works, remedy of faults and disposal**

- Fixed Adjusting-, maintenance- and inspectionworks and time intervals including Details for exchange of parts/part components as mentioned in the instructions for use are to be adhered.  
These works must only be carried out by expert personal.
- After maintenance- and repair works loose screw connections must always be firmly tightened!

**Guarantee and liability**

- Our „General conditions of selling and delivering“ are in force.  
There will be no guarantee or liability for injuries of persons or things if these injuries are caused by one or by some of the following reasons.
- Inappropriate use of the lift.
- Inappropriate installation, initiation, operation and maintenance of the lift.
- Use of the lift while one or several security devices do not work or do not work correctly or are not installed correctly.
- Not to follow the regulations of the operating instruction concerning transport, storing, installation, initiation, operation and maintenance of the lift.
- Changes of the construction of the lift without asking the producer.
- Changes of important adjustments of the lift (e.g. driving elements, power rating, motor speed, etc)
- Wrong or incorrect maintenance.
- Catastrophes, acts of God or external reasons.



*Fill out, undersign and copy this sheet and send the original to the lift manufacturer. The copy remains in the Manual.*

**Otto Nußbaum Hebetechnik GmbH & Co. KG**  
**Korker Straße 24**  
**D-77694 Kehl-Bodersweier**

### **Record of installation**

The automotive lift UNI 3500 CLT / PLUS with the

serial number:..... was installed on:.....

at the firm:..... at:.....

the safety was checked and the lift was started.

The installation was effected from the operating authority/competent (please delete as applicable).

The safety of the automotive lift was checked from the competent before the initial operation.

The operating authority attest the installation of the automotive lift, the competent attest the correct initial operation.

..... date ..... name of the operating authority ..... signature of the operating authority

..... date ..... name of the competent person ..... signature of the competent person

Your customer service:.....

**Record of handing over**

The automotive lift UNI 3500 CLT / PLUS with the  
serial number: ..... was installed on: .....  
at the firm: ..... at: .....  
the safety was checked and the lift was started.

The persons below were introduced after the installation of the automotive lift. The introduction was carried out from an erector of the lift-manufacturer or from a franchised dealer (competent person).

..... date	..... name	..... signature
..... date	..... name of competent	..... signature of the competent

Your customer service:.....

## 1. Introduction

The document "**Operating Instruction and Documentation**" contains important information about installation, operation and maintenance of the lift.

To furnish proof of the **installation of the automotive lift** the form "Record of Installation" must be signed and returned to the manufacturer.

To furnish proof of the singular, regular and extraordinary check this documentation contains forms. The forms should be used to document the checks. They should not be removed from this documentation.

Every **change of the construction** and **displacement** of the automotive lift has to be registered in the "**Master document**" of the lift.

### 1.1 Installation and check of the automotive lift

Only specialist staff is allowed to do work concerning safety and to do the safety checks of the lift. They are called experts and competent persons in this document.

Experts are persons (for example self-employed engineers, experts) which have received instruction and have experience to check and to test automotive lifts. They know the relevant regulations concerning both labour and accidents prevention.

Competent persons are persons who have acquired adequate knowledge and experience with automotive lifts. They took part in training from the lift-manufacturer (servicing technicians of the manufacturer or dealer are competent)

### 1.2 Information of Warning

To show danger and to show important information the three symbols below are used. Pay attention to those passages, which are marked with these symbols



*Danger! This sign indicates danger to life. Inexpert handling of the described operation may be dangerous to life.*



*Caution! This sign cautions against possible damage to the automotive lift or other material defects in case of inexpert handling .*



*Attention! This sign indicates an important function or another important note.*

## 2. Master document of the automotive lift

### 2.1 Lift-manufacturer

Otto Nußbaum Hebetechnik GmbH & Co. KG  
Korker Straße 24  
D-77694 Kehl-Bodersweier

### 2.2 Application

The automotive lift UNI-LIFT 3500 CLT / Plus is a lifting mechanism for lifting motor vehicles with a laden weight of up to 4000 kg (with wheel free lift 3500 kg). The max. load distribution is 2:1 in or against drive-on direction.

The wheel free lift is a lifting mechanism for lifting motor vehicles with a laden weight of up to 3500 kg. The max. load distribution is 2:1 in or against drive-on direction.

The automotive lift is only designed for servicing vehicles. It is not allowed to carry persons with the lift. It is not allowed to climb on the lift or on the vehicle. It's not allowed to install the standard-automotive lift in a hazardous location or washing bays.

After changes of the construction after essential maintenance work on carrying parts and after changing the installation place, an expert has to check the lift and to confirm its correctness and security.

### 2.3 Changes at the construction

**Changes at the construction, expert checking, resumption of work**  
(date, kind of change, signature of the expert)

.....  
.....  
.....

name, address of the expert

.....

.....

place, date

signature of the expert

### 2.4 Displacement of the automotive-lift

**Displacement of the automotive-lift, expert checking, resumption of work**  
(date, kind of change, signature of the expert)

.....  
.....  
.....

name, address of the expert

.....

.....

place, date

signature of the expert

## 2.5 Declaration of conformity

### Nussbaum



Konformitätserklärung

Declaration of Conformity

Déclaration de conformité

Declaración de conformidad

Dichiarazione di conformità

gemäß Maschinenrichtlinie 98/37/EG Anhang II.



OTTO NUBBAUM GmbH&Co. KG

Korker Str.24

D - 77694 Kehl-Bodersweier

Hiermit erklären wir, daß die Hebebühne, Modell ...

Hereby we declare that the lift model ...

Déclare par la présente que le pont élévateur modèle ...

Por la presente declara, que el elevador modelo ...

Con la presente dichiariamo che il ponte sollevatore modello ...

Typ: UNILIFT 3500 CLT

Seriennummer: \_\_\_\_\_

in Übereinstimmung mit den folgenden EG – Richtlinien und harmonisierten Normen gefertigt wurde

was manufactured in conformity with EC directives and the harmonized norms

fabriqué en conformité avec les directives européennes suivantes et selon les normes harmonisées en vigueur.

producido de acuerdo a las siguientes reglas de la Comunidad Europea y normas harmonizadas,

è stato costruito in conformità con le direttive CE e le relative norme armonizzate

98/37EG

Maschinenrichtlinie

EN 1493: 1998

Fahrzeug- Hebebühnen

EN 60204:1992

Sicherheit von Maschinen – Elektrische Antriebe

Prüfinstitut – Certification institute  
Organisme certificateur – Ente certificatore

Registrier Nr. – Registered No.  
Enregistrement N° - Registrazione Nr.

CE 0044 (RWTÜV)

04 205 2366/00

Kehl, 21.09.2004

Otto Nussbaum GmbH & Co. KG  
Korker Str. 24  
77694 Kehl  
Thomas Flässler

### 3. Technical information

#### 3.1 Technical ratings

capacity without wheel free lift	4000 kg
with wheel free lift	3500 kg
load distribution	max. 2:1 in or against drive-on direction
Lifting time (main lift)	approx. 31 sec. with load
Lowering time (main lift)	approx. 17 sec. with load
Maximal lifting height:	1930 mm
capacity wheel free lift	2500 kg
load distribution	max. 2:1 in or against drive-on direction
Lifting time (wheel free lift)	approx. 13 sec. with load
Lowering time (wheel free lift)	approx. 15 sec. with load
Maximal lifting height	580 mm
Line voltage	3 x 400 Volt , 50Hz
Power rating	3 kW
Motor speed	3000 rot./min.
Pump capacity	3 ccm
Hydraulic pressure main lift	ca. 240 bar with load
Hydraulic pressure wheel free lift	ca. 215 bar with load
pressure relief valve main lift	ca. 260 bar
pressure relief valve unlocking cylinder	ca. 40 bar
Oil tank	approx. 40 Litre
Sound level	≤ 75 dBA
Connection by customer	3~/N+PE, 400V, 50 Hz (standard version) with fuse T16A  (Pay attention to the voltage of your state)

#### 3.2 Security devices

1. Pressure relief valve  
    Overprint-safety of the hydraulic system
2. Holding valve  
    safety device against unintentional lowering
3. Lockable main switch  
    safety device against unauthorised operation
7. CE-STOP  
    safety device against squeeze
5. Hydraulic unblockable security system at the cylinders  
    safety device against unintentional lowering of the wheel free lift
6. Interactive security system

- The Safety-Star-System (SST) controls the actions of the lift while the lift lowers or raises.
- Normally, the lift lowers with a speed of 0,05 meters in a second.  
If the speed increases, e.g. because of a leakage of the hydraulic system, the SST detects the problem and stops the lift by closing the oil supply of the hydraulic cylinders.
- Switch off the main switch.
- Control the complete hydraulic system and call your service partner if there is any defect!
- The lift can be repaired by a competent person with knowledge and experience, who has joined a special training of the lift manufacturer (Erectors of the manufacturer and its retailers are competent persons).


### **CE-STOP (main lift and wheel free lift)**

- When rail of the lift is approximately 320 mm high, the lowering stops automatically.
- Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
- Push the button „lowering“ and keep it pushed until the lift has reached his lowest position. You hear an acoustic signal while you lower the lift in his end-position.

### **Top-limit**


- When the lift has reached his maximal height the SST stops the lift automatically.


## 3.3 Datasheet




<b>Nussbaum</b>	<b>HEBETECHNIK</b>
UNI-Lift 3500 CLT	EINBAU2215
30.08.2000 / VEID	
	www.nussbaum-lifts.de 77694 KEHL-BODERSWEILER

Mass- und Konstruktionsänderungen vorbehalten!







ACHTUNG: GILT NUR FUER DIE SERIENAUSFUEHRUNG MIT STELLPLATTEN UND  
BEIDSEITIGEN AUFFAHRKLAPPEN.

ANSTELLE DES LEITUNGSKANALS KANN AUCH EIN LEERROHR

$\varnothing$  100 VERlegt WERDEN.

BAUSETS IST FOLgendES ANZUBRINGEN:  
NETZANSCHLUSS 3 /N+PE, 400V, 50Hz, KABELLAENGE CA. 2m  
WASSERABFLUSS IN DER VERTIEFUNG

Gilt auch fuer Radfreiheber bodeneben!


GRUBENMASSE UNI-LIFT 3500 CLT / NT  
mit durchgehender Grube fuer Achsheber, Oberkante Achsmesset bodeneben,  
Schienenloenge 4 500 mm

24.10.2000 / M.A

EINBAU2231-1

**NUßBAUM**  
**HEBETECHNIK**

FERTIGUNGSTECHNIK + MASCHINENBAU  
77694 KEHL-BODERSWEIER



ACHTUNG: GILT NUR FÜR DIE SERIENAUSFÜHRUNG MIT STELPLATTEN UND

BEIDSEITIGEN AUFAHKLAPPEN.

ANSTELLE DES LEITUNGSKANALS KANN AUCH EIN LEERROHR

$\varnothing$  100 VERlegt WERDEN.

BAUSEITS IST FOLgendES ANZUBRINGEN:

NETZANSCHLUSS 3 /N+PE, 400V, 50Hz, KABELLAENGE CA. 2m

WASSERABFLUSS IN DER VERTIEFUNG

GRUBENMASSE UNI-LIFT 3500 CLT / NT


OBERKANTE ACHSMESSESET UND RADFREIHEBER BODENEBEN, SCHIENENLÄNGE 4500 MM

25.10.2000 / M.A

EINBAU2232

**NUßBAUM**  
**HEBETECHNIK**

FERTIGUNGSTECHNIK + MASCHINENBAU  
77694 KEHL-BODERSWEIER



ACHTUNG: GILT NUR FÜR DIE SERIENAUSFÜHRUNG MIT STELLPLATTEN UND BEIDSEITIGEN AUFAHKLAPPEN.

ANSTELLE DES LEITUNGSKANALS KANN AUCH EIN LEERROHR  
Ø 100 VERlegt WERDEN.

BAUSEITS IST FOLgendES ANzUBRINGEN: NETZANSCHLUSS 3 /N+PE, 400V, 50Hz, KABELLAENGE CA. 2m  
WASSERABFLUSS IN DER VERTIEFUNG

GRUBENMASSE UNI-LIFT 3500 CLT / NT


OBERKANTE AUFAHRSCHIENE BODENEBEN, SCHIENENLÄNGE 4500 MM

29.09.2000 / M.A

EINBAU2226

**NUßBAUM**  
**HEBETECHNIK**

FERTIGUNGSTECHNIK + MASCHINENBAU  
77694 KEHL-BODERSWEIER



ACHTUNG: GILT NUR FÜR DIE SERIENAUSFÜHRUNG MIT STELPLATTEN UND BEIDSEITIGEN AUFFAHRKLAPPEN.  
ANSTELLE DES LEITUNGSKANALS KANN AUCH EIN LEERROHR  
 $\varnothing$  100 VERlegt WERDEN.

BAUSETS IST FOLgendes ANzUBRingen: NETZANSCHLUSS 3 /N+PE, 400V, 50Hz, KABELLAENGE CA. 2m  
WASSERABFLUSS IN DER VERTIEFUNG

GRUBENMASSE UNI-LIFT 3500 CLT / NT  
mit durchgehender Grube für Achsheber, Oberkante Auffahrschiene bodeneben,  
Schienelänge 4500 mm

04.10.2000 / M.A

EINBAU2227

**NUßBAUM**  
HEBETECHNIK

FERTIGUNGSTECHNIK + MASCHINENBAU  
77694 KEHL-BODERSWEIER

## 4. Safety regulations

Using automotive lifts for working the regulations of accident EN1493/Aug.98 (CEN/TC 98 „Automotive lifts“) must be observed.

**Especially the following regulations are very important:**

- The laden weight of the lifted vehicle mustn't be more than 4000 kg for the automotive lift, 3500 kg for the automotive lift with wheel free lift.
- The laden weight of the lifted vehicle musn't be more than 2500 kg for the wheel free lift.
- The automotive lift must be lowered completely, before the vehicle is driving, in the provided direction, on the lift.
- During working with the lift the operating instruction has to be followed.
- At vehicles with low sub-ground clearance or with optional equipment (sport equipment) or sport-vehicles, it is to be tested previously whether damages can appear.
- Only trained personnel over the age of 18 years old are to operate this lift.
- Position the polymer supports as described of the vehicle manufacturer under the vehicle. (Version with wheel free lift)
- The correct position of the polymer pads has to be checked after the vehicle has been lifted a little bit.
- It's not allowed to stay under the lifted or lowered vehicle (except for the operator).
- Check the center of gravity of the vehicle if heavy parts are removed. (Version with wheel free lift)
- It's not allowed to transport passengers on the lift or in the vehicle.
- It's not allowed to climb onto the lift or onto a lifted vehicle.
- The automotive lift must be checked from an expert after changes in construction or after repairing carrying pads.
- It's not allowed to start with operations at the lift before the main switch is switched off.
- During lifting or lowering the vehicle it must be observed from the operator.
- It's not allowed to install the standard-automotive lift in hazardous location or in washing bays.

## 5. Operating instructions



*The Safety Regulations must be observed during working with the automotive lift.  
Read the safety regulations in chapter 4 carefully before working with the lift!*

## 5.1 Lifting the vehicle

- Drive vehicle over the lift, longitudinal axes on line of the lift.
- Block the vehicle against rolling, put into gear.
- Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
- Switch on the control system; main switch on position "1" (see pic.1)
- Raise the lift. Press the button „lifting“.
- Lift the vehicle on the working height.
- Observe the complete process.

*pic. 1: operation unit*



*main switch*

button „lifting“ main lift.....	Bühne
button „lowering“ main lift.....	Bühne
button „lifting“ wheel free lift.....	R.F.H.
button „lowering“ wheel free lift.....	R.F.H.
light.....	Licht
equalization.....	Ausgleichen

## 5.2 Lowering the vehicle

- Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
- Lower the vehicle to the working height or until the platform reaches the lowest point; press the button „lowering“ .
- Before the lift reaches the lowest position, it stops (approx. 150 mm). Let off the „lowering“. Control the dangerous places. Press the button again. You hear an acoustic signal until the lift reaches the lowest position.
- Observe the complete process.
- Drive the vehicle out of the lift if the lift (main lift) is in the lowest position.

## 5.3 Lifting the vehicle with the wheel free lift

- Drive vehicle over the lift, longitudinal axes on line of the lift.
- Block the vehicle against rolling, put into gear.
- Position the polymer supports under the pick-up points which are described by the vehicle manufacturer. Do not lay them on edge! The vehicle might fall down!
- Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
- Switch on the control system; main switch on position "1" (see pic.1)
- Raise the lift. Press the button „lifting“ (R.F.H.)

- Lift the vehicle on the working height.
- Observe the complete process.

#### **5.4 Lowering the vehicle with the wheel free lift**


- Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
- Lower the vehicle to the working height or until the platform reaches the lowest point; press the button „lowering“ (R.F.H.)
- Before the lift reaches the lowest position, it stops (approx. 150 mm). Let off the button „lowering“. Control the dangerous places. Press the button again. You hear an acoustic signal until the lift reaches the lowest position
- When the lift is in its lowest position, remove the polymer supports
- Drive the vehicle out of the lift if the lift (main lift) is in the lowest position.

#### **5.5 Equalisation of the 2 rails (main lift)**

- Press button „Equalize“ at the operation unit. The rails of the main lift equalize. It is not possible to equalize the wheel free lift with this button.

#### **5.6 Manual equalisation of the lift**

- If the SST (Safety-Star-System) makes out a difference of approx. 40 mm, it will stop the lift automatically.
- An equalisation has to be prepared
- Remove the top covers of the aggregate and the covers of the control box.
- In the control box unit you find the DIP-switches.



Dip-switch on the board in the box.

***An access on the Dip-Switch is only allowed when the main switch is switched off and only by instructed, authorized technical staff.***

- Dip-switch 5 (regulation ON/OFF).
- Dip-switch 1 (only platform 1 moveable).
- Dip-switch 2 (only platform 2 moveable).
- Dip-switch 7 (reset – adjust to zero the lift in the lowest position).

##### **Enforce the equalisation:**

- Equalize platform 1.
- Move the Dip Switch 5 on position “off” (regulation off).

- Move the Dip switch 1 on Position “on” (Dip switch 1 for platform 1).
- Press the button „lifting“ or „lowering“ and simultaneously the override switch until the platform has the same height.
- Move the Dip switch 1 on Position „off“.
- Move the Dip switch Dip 5 on Position „on“ (regulation on).
- Press the button „lowering“ until the lift reaches the lowest position to do a reset (compare chapter „Reset after a emergency lowering“)
- Mount the covers again.

## 6. Troubleshooting

If the lift does not work properly, the reason for this might be quite simple. Please check the lift for the potential reasons mentioned on the following pages. If the cause of trouble cannot be found, please call the technical service.

### Problem: Motor does not start!

Potential causes:

- *no power supply*
- *main switch is not engaged*
- *fuse defective*
- *the feed line is cut*
- *thermal switch in the motor is active*

solution:

- Check the power supply*
- Check the main switch*
- Check the fuse*
- Check the feed line*
- Let it cool down*

### Problem: Motor starts, lift does not lifting!

Potential causes:

- *The vehicle is too heavy*
- *Level of the oil is too low*
- *The emergency lowering screws are not closed*
- *The hydraulic hoses are dirty*

solution:

- Unload the vehicle*
- Fill in new hydraulic oil*
- Check screws and close/secure them*
- Call the lift service*

### Problem: The lift does not lowered!

Potential causes:

- *The lift is standing on a obstacle*
- *The hydraulic valve is defective*
- *fuse defective*
- *button „lowering“ is not pressed*
- *the holding valve is defective*

solution:

- See chapter 6.1*
- Call the lift service*
- Check the fuse*
- Check the button*
- Call the lift service*

## Problem: The equalizing does not work

Potential causes:

- wrong button pressed
- hydraulic valve defective
- fuse defective

solution:

- Check the button*
- Call the lift service*
- Check the fuse*

## 6.1 Driving on an obstacle


If the Safety-Star-System recognizes a difference of 40 mm between the platforms then it switches off the lift.

### 6.1.1 Remove an obstacle



***Only trained and authorized staff is allowed to work with the DIP-switches! The main-switch has to be switched off!***

- Remove the cover of the operating unit and the control box.
- Press the button „Reset“ (1) and hold it. (see pic. 2, „Reset Achskontroller 1“)



- Carefully watch the car on the lift and its reaction.
- Press the „lifting“ button until the obstacle can be removed.
- The side of the lift that is higher must be lowered with the help of the corresponding Dip-switch. (see chapter „Equalisation of the two lifting platforms“).
- After the equalizing of the runways, a reset has to be done (see the following points).
- Move all the Dip-switches on position „off“.
- Move the Dip-switch 5 on position „on“.
- Press the button „reset“ (1) and hold it. (pic. 2)
- Switch-off the main switch and wait 5 sec. Hold the reset button.
- Switch-on the main switch and wait 5 sec. Hold the reset button.
- Let go off the reset button.
- Press the button „lowering“ until the lift (both platforms) is in the lowest position and the acoustic signal stops beeping.
- Move the Dip-switch 7 on position „on“.
- Dip-switch 5 stays on „on“ position.
- Press the button „reset“ (1) and hold it.
- Switch-off the main switch and wait 5 sec. Hold the reset button.
- Switch-on the main switch and wait 5 sec. Hold the reset button.
- Let go off the reset button.
- Dip-switch 5 stays in „on“ position.
- Move the Dip-switch 7 on position „off“.
- On the computer-board must now three diodes lighten permanently. One additional diode must be blinking in the frequency of approx. 1 sec.
- Raise and lower the automotive lift a few times without load. Observe the process.
- Mount the covers.

## 6.2 Emergency lowering of the main lift/ wheel free lift



*A emergency lowering is an intervention into the control of the lift and can be done only by experienced expert.*

*The emergency lowering must be carried in this order. Otherwise a malfunction can lead it to damages or lead to danger for body and lives.*



*Every kind of external leakage has to be removed. This is necessary in particular before an emergency lowering.*

*The emergency lowering may only be done by persons which are trained in using the lift.*

UNI CLTAggre.jpg



*pic.3: hydraulic bloc*

Reasons, that can make an emergency lowering necessary, are e.g. a defect of the electric system or disturbances of the valves, etc.

In the case of **power failure**, the emergency-lowering can only be done if the automotive-lift is not blocked in a safety device. If the lift is locked, the command valve cannot be opened and the security system cannot be opened. Wait for the end of the blackout in this case.

In the case of **defective electromagnetic valves**, the hydraulic valves of the lift will not open any more. Therefore the lift can not be lowered. In this case there is the possibility to open the hydraulic valves manually and to lower the lift into its lowest position, so that the vehicle can be driven off.


### **Preparation for the emergency lowering**

1. Switch off the main switch and safe it. (lock it)



*The emergency lowering can only be performed when the interactive Safety-Star-System is not locked.*

2. Open the hydraulic screwing B1 (see pic. 4) at the aggregat. Connect a hydraulic hand pump which includes a back pressure valve with the hydraulic hose. Generate approximately 30-35 bar pressure with the hand pump.



*pic. 4: connection scheme for the hand pump*

3. Connect the hand pump afterwards with the measuring connection M3 at the hydraulic bloc. Approximately 100 bar are needed to raise one rail of the lift 10 mm.

4. Afterwards connect the hand pump with the measuring connection M4 at the hydraulic block. Approximately 100 bar are needed to raise the other rail of the lift 10 mm.
5. Unlock the security system manually in the direction of the arrow (see pic.).



*pic. 5: unlocking the cylinders*

6. Repeat point (2) to secure that the unlocking cylinders are not locked any more.
7. Execute this process at both cylinders.

#### **Procedure of the emergency lowering (main lift)**

- Condition: The security system is not locked.
- Open the locknut N1 & N2 (red) of the hydraulic block
- Turn carefully, maximal one rotation anticlockwise, the emergency-lowering screw N1 with a suitable tool (hexagon spanner 5). The lowering of one platform starts. Lower the platform approx. 5- 10 cm then close the emergency-lowering screw. If the platform does not lower, the cylinder is locked. Repeat the process of unlocking the cylinder.
- Repeat the procedure with the set screw N2. Repeat this alternate with the set screws N1 and N2 until the lift has reached his lowest position.
- If the lift is in the lowest position turn the set screws clockwise and safe it with the locknuts.
- Remove the hand pump and the objects between the cylinder and the flange!



*The complete process must be observed by the operator. Close the emergency lowering screws when any danger appears. After finishing the emergency lowering, the set screws and the locknuts must be brought back into the original position, otherwise a malfunction of the lift may occur.*



*Do not use the lift until defective parts are exchanged!!*




*Before the initiation after an emergency lowering, the objects between the cylinder and the flange have to be removed! Otherwise the security devices are out of function and this means danger to life and danger of damages!*

### 6.2.2 Preparation for the emergency lowering (wheel free lift)

1. Switch off the main switch and safe it. (lock it)
2. The wheel free lift has to be secured against falling down with suitable objects. These objects are to be removed only briefly before the emergency lowering.

***The emergency lowering can only be performed when the interactive Safety-Star-System is not locked.***


3. Open the hydraulic screwing B1 at the aggregate .Connect a hydraulic hand pump which includes a back pressure valve with the hydraulic hose. Impinge the hand pump with maximal approximately 30- 35 bar.



Handpu Notab CLT Plus.jpg

pic. : connection scheme for the hand pump

4. Remove only the hydraulic hand pump. The back pressure valve remains at the hydraulic hose.
5. Open the connection A3 at the hydraulic unit. Connect the hand pump with a T-piece and a back pressure valve at the connection A3.



Hand\_Notab CLT RFH.jpg

pic. : Connection for the emergency lowering of the wheel free lift

6. Approximately 100 bar are needed to lift a rail of the wheel free lift approximately 10 mm.
7. Remove only the hydraulic hand pump. Open the connection A4 at the hydraulic unit Connect the hand pump with a T-piece and a back pressure valve at the connection A4.
8. Approximately 100 bar are needed to lift the second rail of the wheel free lift approximately 10 mm.
9. Repeat point (3) to secure that the security system is unlocked.



pic 6: positions of the seat valves

### **Procedure of the emergency lowering (wheel free lift)**

- Condition: The security system isn't locked.
- The double seat valves SV1, SV2, SV3, SV4 are to be pressed manually. Further persons might simplify this procedure (see pic. 6).
- The double seat valves are pressed.
- Open the locknut N1 & N2 (red) of the hydraulic block
- Turn carefully, maximal one rotation anticlockwise, the emergency-lowering screw N1 with a suitable tool (hexagon spanner 5). The lowering of one platform starts. Lower the platform approx. 5- 10 cm then close the emergency-lowering screw. If the platform does not lower the cylinder is locked. Repeat the process of unlocking the cylinder.
- Repeat the procedure with the set screw N2. Repeat this alternate with the set screws N1 and N2 until the lift has reached his lowest position.
- If the wheel free lift is in the lowest position turn the set screws clockwise and safe it with the locknuts.
- Let off the double seat valves.
- Remove the hand pump and the objects between the cylinder and the flange!



*The complete process must be observed by the operator. Close the emergency lowering screws when any danger appears. After finishing the emergency lowering, the set screws and the locknuts must be brought back into the original position, otherwise a malfunction of the lift may occur.*



*Do not use the lift until defective parts are exchanged!!*



*Before the initiation after an emergency lowering, the objects between the cylinder and the flange have to be removed! Otherwise the security devices are out of function and this means danger to life and danger of damages!*

### **6.3 Reset the main lift after an emergency lowering**



*Only when the lift is in the lowest position is the reset of the lift possible.*



*An access on the Dip-Switch is only allowed when the main switch is switched off and only by instructed, authorized technical staff.*

- a) There must not be a vehicle on the lift.
- b) Remove the cover of the operating unit.
- c) Remove the cover of the electrical large box.
- d) Press the button 1 (see pic. 2) and hold it.
- e) Switch-off the main switch and wait 5 sec. Hold the reset button.
- f) Switch-on the main switch and wait 5 sec. Hold the reset button.
- g) Let go off the reset button.
- h) Press the button „lowering“ until both platforms are in the lowest position.
- i) If necessary repeat several times the steps d) until h) so that the lift is surely in the lowest position.
- j) After that move the Dip-switch 7 on position „on“.
- k) Dip-switch 5 stays on position „on“.
- l) Repeat the steps d) until h)
- m) After that, move the Dip-switch 7 on position „off“. Dip-switch 5 stays on position „on“.
- n) On the computer-board must now three diodes lighten permanently. One additional diode must be blinking in the frequency of approx. 1 sec.
- o) Raise and lower the automotive lift a few times without load. Observe the process.
- p) Mount the covers.

## 7. Inspection and Maintenance of Nussbaum lifts



*Before a maintenance, all preparations are to enforce that with maintenance-working and repair-working at the lift no danger for body and lives and for damages of objects exists.*

A regular service has to be performed in regular distances of 3 months through the operator in accordance with following service manual.

### 7.1 Maintenance plan of the lift

- Generally do not remove the plastic cover of the piston rod. Only in case of heavy dirt deposit clean the piston rods of the hydraulic cylinders from deposit.
- Grease the piston rods with a high capacity lipid (approx. 5 g of S2 DIN51503 KE2G of the Renolit Company).
- Clean and lubricate the moving parts of the lift (hinge bolts, sliding pieces, sliding surfaces) grease with a multipurpose lipid (example: Auto Top 2000 LTD. Agip).
- Grease the lubricate nipples with a multipurpose lipid. (example: Auto Top 2000 LTD. Agip).
- Check the colour if necessary make a repair.
- Check the hydraulic hoses
- Check the hydraulics-hoses for leakage.
- Check the oil level. Fill in a clean, high quality oil (32 cst)in the tank.
- The hydraulic oil has to be changed at least once a year. To change the oil, lower the lift into the lowest position. Empty the tank and replaced clean oil, approx. 40 litres are needed. A high quality hydraulic oil is recommended, its should be 32 cst. (e.g.g. HLP 32 LTD. OEST Company)

Use a ATF-Suffix hydraulic-oil (OEST Company ) if the ambient temperature is under 5 degree centigrade. After the fill up, the hydraulic oil must be between the upper and low marking of the oil level gauge.

- After § 52-3 of the VBG 14 German regulation, exchange the hydraulic hoses if its necessary, but latest after 6 years.
- Check the welding of the lift.
- Check the safety device of the lift.
- Check the Battery of the controller (ASC). The Battery has a working life at normal business between 4 ½ - 5 Years (manufacturers statement). To avoid a permanent data-loss through an empty battery, the ASC must be sent for after 4 years into the nußbaum headquarter. Please contact your service partner.
- Check the Polymer supports and replace them if its necessary.
- Check the turning moments of the screws.

**Turning moment for screws**

property class 8.8

	0,10*	0,15**	0,20***
M8	20	25	30
M10	40	50	60
M12	69	87	105
M16	170	220	260
M20	340	430	520
M24	590	740	890

Drehmomenttabelle 8.8-10.9 E

property class 10.9

	0,10*	0,15**	0,20***
M8	30	37	44
M10	59	73	87
M12	100	125	151
M16	250	315	380
M20	490	615	740
M24	840	1050	1250

- \* sliding friction 0,10 for very good surfaces, lubricated
- \*\* sliding friction 0,15 for good surfaces, lubricated oder dry
- \*\*\* sliding friction 0,20 surface black or phosphatized, dry

## 7.2 Cleaning of the automotive lift

A regular and appropriate maintenance served the preservation of the lift.

It can be a prerequisite for claims at possible corrosion.

The best protection for the lift is the regular cleaning of dirt of all manner.

- Including this:

- de-icing salt
- sand, pebble stone, natural soil
- industrial dust of all manner
- water ; also in connection with other environmental influences
- aggressive deposit of all manner
- constant humidity by insufficient ventilation

### How often must the lift be cleaned ?

This is dependent on the use, of the working with the lift, of the cleanliness of the workshop and location of the lift. The degree of the dirt is dependent on the season, of the weather conditions and the ventilation of the workshop.

Under bad circumstances it is necessary to clean the lift every week, but a cleaning every month can suffice.

Clean the lift and the floor with a non-aggressive and non-abrasive detergent. Use gentle detergent to clean the parts. Use an standard washing-up liquid and lukewarm water.

- Do not use for cleaning a steam jet cleaning
- Remove all dirt careful with a sponge if necessary with a brush.
- Pay attention that are no remains of the washing-up liquids on the lift after cleaning.
- Do not use aggressive means for cleaning the workshop floor and the automotive lift.

- A permanent contact with every kind of liquid is forbidden. Do not use any high pressure device for cleaning the lift.

## 8. Security check

The security check is necessary to guarantee the safety of the lifting during use. It has to be performed in the following cases:


1. Before the initial operation, after the first installation  
**Use the form “First security check before initiation”**
2. In regular intervals after the initial operation, at least annually.  
**Use the form “Regular security check at least annually”**
3. Every time the construction of that particular lift has been changed.  
**Use the form “Extraordinary security check”**

 *The first and the regular security check must be performed by a competent person. It is recommended to service the lift at this occasion.*

 *After the construction of the lift has been changed (changing the lifting height or capacity for example) and after serious maintenance works (welding on carrying parts) an extraordinary security check must be performed by an expert.*

This manual contains form with a schedule for the security checks. Please us the adequate form for the security checks. The form should remain in this manual after they have been filled out. In the following there is a short description about special safety devices.

## 9. Installation and Initiation



### 9.1 Installation of the automotive lift

You can choose between two installation places of the operating unit: The position of the operating unit can be chosen in drive-in direction right or in drive-in direction left.

## 9.2 Regulations for the installation

- The installation of the lift is performed by trained technicians of the manufacturer or its distribution partner. If the operator can provide trained mechanics, he can install the lift by himself. The installation has to be done according to this regulation.
- The standard lift must not be installed in hazardous locations or washing areas.
- Before installation a sufficient foundation must be proved or constructed.  
An even installation place has to be provided. The foundations must be based in a frost resistance depth, both outside and indoors, where you must reckon with frost.
- An electrical supply 3~/N+PE, 400 V, 50 Hz has to be provided. The supply line must be protected with T16A (VDE0100 German regulation). The minimum diameter amounts to 2,5 mm<sup>2</sup>.
- All cable ducts have to be equipped with protective coverings to prevent accidents.
- After the installation of the automotive-lift, it is necessary to examine by customer the Protective grounding after IEC regulation (60364-6-61). An insulation resistance examination is Also recommended

## 9.3 Erection and doweling of the lift

1. Take carefully out the lift of the wood-crate.  
***Do not pull apart the scissors of the lift !***
2. Install the lift according to the data sheet and the foundation plan.
3. Remove the cover of the operating unit.
4. Install the operating unit according to the datasheet and connect the power supply.
5. Connect the hydraulic hoses and the wires of the measuring system with the aggregate.  
***The hoses and wires should not cross each other***
6. Fill in the hydraulic oil (approx. 40 litres)
6. Press shortly the button „lifting“. Observe the direction of rotation of the motor.
7. If no platform raises, check again the direction of rotation of the motor and change two phases of the power supply if it is necessary (attention: only by 3 phase supply).
9. Press the button „lifting“ until the lift is on a height of approx. 10 cm.
10. Press the button „lowering“ until both platforms are in the lowest position and the acoustic signal cannot be heard anymore.
11. Repeat the steps 7 to 10 until the lift surely is in the lowest position.
12. Press the button „lifting“ until the lift is standing on a height of approx. 30 cm. (above the CE-Stop)
13. Press the button „lowering“ until the lift stops at the CE-Stop. Let the button off.
14. Press the button „lowering“ until both platforms are in the lowest position and the acoustic signal cannot be heard anymore.
15. Repeat the steps 12 till 14.

16. Press the button „lifting“ until the lift reaches the highest position.
17. Press the button „lowering“ until the lift is in the lowest position.
18. Press the button „lifting“ again until the lift reaches the highest position.
19. The lift was adjusted by these individual steps to its normal function.
20. Adjust the lift: first one base plate, than the second base plate. If there is an uneven floor even it with metal sheets. A continuous contact between the floor and the base plate must be guaranteed to avoid hollow spaces.
21. Dowel the lift: **Nussbaum Company demands LIEBIG safety dowels (german dowel manufacturer) or equivalent dowels of other manufacturer but: observe their regulations.**  
Before doweling check the concrete floor (with quality B25!) if the concrete floor goes to the top edge of the floor. For an existing concrete floor the dowels have to be chosen according to pic. 8. If floor tiles are on the concrete floor, the dowels have to be chosen according pic. 9. Its important for the trouble-free working that the base plates are clean and the guides of the sliding block are clean and greased.  
Check the adjustment of the base plates and dowel the lift: Bore the holes to fix the dowels through the borings of the base plates. Clean the holes with pressure air. Put in the safety dowels.
22. Dowel the operating unit.
23. Fine adjustment of the lift: first one base plate, than the second base plate. If there is an uneven floor even it with metal sheets. A continuous contact between the floor and the base plate must be guaranteed to avoid hollow spaces.
24. Tighten the Liebig-dowels with the dynamometric key ( $M = 80\text{Nm}$ ).



***Each dowel must be tightened with the demanded torque. Otherwise the normal function of the lift can not be guaranteed.***

***Observe the regulations of other dowel-manufacturers.***

25. Raise and lower the lift several times with load. Check the torque of the dowels and check the hydraulic parts for tightness.
26. Mount the covers: ***Do not damage the cables.***
27. The lift has now its normal function



***When there are disturbances, the customer service has to be called!***

## **9.4 Initiation**



***Before the initiation a security check must be performed. Therefore use form: First security check.***

If the lift is installed by a competent person, he will perform this security check. If the operator installs the lift by himself, he has to instruct a competent person to perform the security check.

The competent confirms the faultless function of the lift in the installation record and form for the security check and allows the lift to be used.



***Please send the filled installation record to the manufacturer after the installation.***

## **9.5 Changing the installation place**

If the place of installation shall be changed, the new place has to be prepared in accordance to the regulations of the first installation. The changing should be performed in accordance with the following points:

- Raise the lift on approx. 1000 mm.
- Remove the cover of the hydraulic tubes.
- Loose the dowels.
- Lower the lift in the lowest position.
- Loose the plug of the power supply.
- If necessary loose the hydraulic hoses only on the operating unit.
- If necessary use blind plugs to close the hoses.
- Disconnect the power supply.
- Transport the lift to ist new place.
- Install the lift in accordance with chapter 9 “ Installation and Initiation”.



***Use new dowels, the used dowels can not be used anymore.***



***A security check must be performed before reinitiation by a competent person. Use form “Regular security check”***

**Pic. 8: choice of the dowel length without floor pavement or tile surface**




Table to pic. 8

Liebig-dowels

Dowel type	B20/75	B20/100
Drilling depth	a 115	140
Min. anchorage depth	b 85	85
Thickness of concrete	c 180	180
Diameter of bore	d 20	20
Thickness of the lift-pieces	e 0-40	40-65

Number of dowels

16

16

Starting torque

according to dowel manufacturer

### Pic 9: choice of the dowel length with floor pavement or tile surface




Table to pic 9

#### Liebig-dowels

Dowel type	B20/100	B20/125	B20/135	B20/175
Drilling depth	a 140	165	175	215
Min. anchorage depth	b 85	85	85	85
Thickness of concrete	c 180	180	180	180
Diameter of bore	d 20	20	20	20
Thickness of the lift-pieces	e+f 40-65	65-90	90-100	100-140

thickness of floor pavement

Number of dowels 16 16 16 16

Starting torque according to dowel manufacturer

## First security check before installation

Filling out and leave in this manual

kind of check	all right	defect missing	veri-fication	remark
Type plate.....				.....
Short operating instruction.....				.....
Warning designation .....				.....
Function override switch.....				.....
Function button "lifting/lowering".....				.....
Condition / function ramps.....				.....
Function interactive security system.....				.....
General condition of the lift.....				.....
Security of the bolts.....				.....
Condition bolts and bearing.....				.....
Construction (deformation, cracking).....				.....
Torque moment of the dowels.....				.....
Fixed seat of the screws.....				.....
Condition operating unit.....				.....
Condition welding.....				.....
Condition piston rod.....				.....
Condition of the covers.....				.....
Closeness of the hydraulic system.....				.....
Level of hydraulic oil.....				.....
Condition hydraulic hoses.....				.....
Condition electrical wires.....				.....
Function test with vehicle.....				.....
Function equalisation of the rails.....				.....
Function CE-Stop.....				.....
Condition Polymer supports.....				.....
Function test wheel free lift (with vehicle).....				.....
Function lightning.....				.....

( mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....  
(Use another form for verification!)

.....  
signature of the operator

## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri-fication	remark
Type plate.....				.....
Short operating instruction.....				.....
Warning designation .....				.....
Function override switch.....				.....
Function button "lifting/lowering" .....				.....
Condition / function ramps.....				.....
Function interactive security system.....				.....
General condition of the lift.....				.....
Security of the bolts.....				.....
Condition bolts and bearing.....				.....
Construction (deformation, cracking).....				.....
Torque moment of the dowels.....				.....
Fixed seat of the screws.....				.....
Condition operating unit.....				.....
Condition welding.....				.....
Condition piston rod.....				.....
Condition of the covers.....				.....
Closeness of the hydraulic system.....				.....
Level of hydraulic oil.....				.....
Condition hydraulic hoses.....				.....
Condition electrical wires.....				.....
Function test with vehicle.....				.....
Function equalisation of the rails.....				.....
Function CE-Stop.....				.....
Condition Polymer supports.....				.....
Function test wheel free lift (with vehicle).....				.....
Function lightning.....				.....

( mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

(Use another form for verification!)

signature of the operator



Filling out and leave in this manual

## Regular security check

kind of check	all right	defect missing	veri-fication	remark
Type plate.....				.....
Short operating instruction.....				.....
Warning designation .....				.....
Function override switch.....				.....
Function button "lifting/lowering".....				.....
Condition / function ramps.....				.....
Function interactive security system.....				.....
General condition of the lift.....				.....
Security of the bolts.....				.....
Condition bolts and bearing.....				.....
Construction (deformation, cracking).....				.....
Torque moment of the dowels.....				.....
Fixed seat of the screws.....				.....
Condition operating unit.....				.....
Condition welding.....				.....
Condition piston rod.....				.....
Condition of the covers.....				.....
Closeness of the hydraulic system.....				.....
Level of hydraulic oil.....				.....
Condition hydraulic hoses.....				.....
Condition electrical wires.....				.....
Function test with vehicle.....				.....
Function equalisation of the rails.....				.....
Function CE-Stop.....				.....
Condition Polymer supports.....				.....
Function test wheel free lift (with vehicle).....				.....
Function lightning.....				.....

( mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

Initiation not permitted, verification necessary

Initiation possible, repair failures until.....

No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....  
(Use another form for verification!)

.....  
signature of the operator

## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri-fication	remark
Type plate.....				.....
Short operating instruction.....				.....
Warning designation .....				.....
Function override switch.....				.....
Function button "lifting/lowering".....				.....
Condition / function ramps.....				.....
Function interactive security system.....				.....
General condition of the lift.....				.....
Security of the bolts.....				.....
Condition bolts and bearing.....				.....
Construction (deformation, cracking).....				.....
Torque moment of the dowels.....				.....
Fixed seat of the screws.....				.....
Condition operating unit.....				.....
Condition welding.....				.....
Condition piston rod.....				.....
Condition of the covers.....				.....
Closeness of the hydraulic system.....				.....
Level of hydraulic oil.....				.....
Condition hydraulic hoses.....				.....
Condition electrical wires.....				.....
Function test with vehicle.....				.....
Function equalisation of the rails.....				.....
Function CE-Stop.....				.....
Condition Polymer supports.....				.....
Function test wheel free lift (with vehicle).....				.....
Function lightning.....				.....

( mark here applicable, in case of verification mark in addition to the first mark! )

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

Initiation not permitted, verification necessary  
Initiation possible, repair failures until.....  
No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....  
(Use another form for verification!)

signature of the operator

## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri-fication	remark
Type plate.....				.....
Short operating instruction.....				.....
Warning designation .....				.....
Function override switch.....				.....
Function button "lifting/lowering".....				.....
Condition / function ramps.....				.....
Function interactive security system.....				.....
General condition of the lift.....				.....
Security of the bolts.....				.....
Condition bolts and bearing.....				.....
Construction (deformation, cracking).....				.....
Torque moment of the dowels.....				.....
Fixed seat of the screws.....				.....
Condition operating unit.....				.....
Condition welding.....				.....
Condition piston rod.....				.....
Condition of the covers.....				.....
Closeness of the hydraulic system.....				.....
Level of hydraulic oil.....				.....
Condition hydraulic hoses.....				.....
Condition electrical wires.....				.....
Function test with vehicle.....				.....
Function equalisation of the rails.....				.....
Function CE-Stop.....				.....
Condition Polymer supports.....				.....
Function test wheel free lift (with vehicle).....				.....
Function lightning.....				.....

( mark here applicable, in case of verification mark in addition to the first mark! )

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....  
(Use another form for verification!)

.....  
signature of the operator

## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri-fication	remark
Type plate.....				.....
Short operating instruction.....				.....
Warning designation .....				.....
Function override switch.....				.....
Function button "lifting/lowering".....				.....
Condition / function ramps.....				.....
Function interactive security system.....				.....
General condition of the lift.....				.....
Security of the bolts.....				.....
Condition bolts and bearing.....				.....
Construction (deformation, cracking).....				.....
Torque moment of the dowels.....				.....
Fixed seat of the screws.....				.....
Condition operating unit.....				.....
Condition welding.....				.....
Condition piston rod.....				.....
Condition of the covers.....				.....
Closeness of the hydraulic system.....				.....
Level of hydraulic oil.....				.....
Condition hydraulic hoses.....				.....
Condition electrical wires.....				.....
Function test with vehicle.....				.....
Function equalisation of the rails.....				.....
Function CE-Stop.....				.....
Condition Polymer supports.....				.....
Function test wheel free lift (with vehicle).....				.....
Function lightning.....				.....

( mark here applicable, in case of verification mark in addition to the first mark! )

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

Initiation not permitted, verification necessary  
Initiation possible, repair failures until.....  
No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....  
(Use another form for verification!)

.....  
signature of the operator

## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri-fication	remark
Type plate.....				.....
Short operating instruction.....				.....
Warning designation .....				.....
Function override switch.....				.....
Function button "lifting/lowering".....				.....
Condition / function ramps.....				.....
Function interactive security system.....				.....
General condition of the lift.....				.....
Security of the bolts.....				.....
Condition bolts and bearing.....				.....
Construction (deformation, cracking).....				.....
Torque moment of the dowels.....				.....
Fixed seat of the screws.....				.....
Condition operating unit.....				.....
Condition welding.....				.....
Condition piston rod.....				.....
Condition of the covers.....				.....
Closeness of the hydraulic system.....				.....
Level of hydraulic oil.....				.....
Condition hydraulic hoses.....				.....
Condition electrical wires.....				.....
Function test with vehicle.....				.....
Function equalisation of the rails.....				.....
Function CE-Stop.....				.....
Condition Polymer supports.....				.....
Function test wheel free lift (with vehicle).....				.....
Function lightning.....				.....

( mark here applicable, in case of verification mark in addition to the first mark! )

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

Initiation not permitted, verification necessary  
Initiation possible, repair failures until.....  
No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....  
(Use another form for verification!)

.....  
signature of the operator

## Regular security check

Filling out and leave in this manual

kind of check	all right	defect missing	veri- fication	remark
Type plate.....				.....
Short operating instruction.....				.....
Warning designation .....				.....
Function override switch.....				.....
Function button "lifting/lowering".....				.....
Condition / function ramps.....				.....
Function interactive security system.....				.....
General condition of the lift.....				.....
Security of the bolts.....				.....
Condition bolts and bearing.....				.....
Construction (deformation, cracking).....				.....
Torque moment of the dowels.....				.....
Fixed seat of the screws.....				.....
Condition operating unit.....				.....
Condition welding.....				.....
Condition piston rod.....				.....
Condition of the covers.....				.....
Closeness of the hydraulic system.....				.....
Level of hydraulic oil.....				.....
Condition hydraulic hoses.....				.....
Condition electrical wires.....				.....
Function test with vehicle.....				.....
Function equalisation of the rails.....				.....
Function CE-Stop.....				.....
Condition Polymer supports.....				.....
Function test wheel free lift (with vehicle).....				.....
Function lightning.....				.....

( mark here applicable, in case of verification mark in addition to the first mark! )

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....  
(Use another form for verification!)

.....  
signature of the operator

## Regular security check

Filling out and leave in this manual

kind of check	all right	defect missing	veri-fication	remark
Type plate.....				.....
Short operating instruction.....				.....
Warning designation .....				.....
Function override switch.....				.....
Function button "lifting/lowering".....				.....
Condition / function ramps.....				.....
Function interactive security system.....				.....
General condition of the lift.....				.....
Security of the bolts.....				.....
Condition bolts and bearing.....				.....
Construction (deformation, cracking).....				.....
Torque moment of the dowels.....				.....
Fixed seat of the screws.....				.....
Condition operating unit.....				.....
Condition welding.....				.....
Condition piston rod.....				.....
Condition of the covers.....				.....
Closeness of the hydraulic system.....				.....
Level of hydraulic oil.....				.....
Condition hydraulic hoses.....				.....
Condition electrical wires.....				.....
Function test with vehicle.....				.....
Function equalisation of the rails.....				.....
Function CE-Stop.....				.....
Condition Polymer supports.....				.....
Function test wheel free lift (with vehicle).....				.....
Function lightning.....				.....

( mark here applicable, in case of verification mark in addition to the first mark! )

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....  
(Use another form for verification!)

.....  
signature of the operator

## **Extraordinary security check before initiation**

 Filling out and leave in this manual

kind of check	all right	defect missing	veri- fication	remark
Type plate.....				.....
Short operating instruction.....				.....
Warning designation .....				.....
Function override switch.....				.....
Function button "lifting/lowering".....				.....
Condition / function ramps.....				.....
Function interactive security system.....				.....
General condition of the lift.....				.....
Security of the bolts.....				.....
Condition bolts and bearing.....				.....
Construction (deformation, cracking).....				.....
Torque moment of the dowels.....				.....
Fixed seat of the screws.....				.....
Condition operating unit.....				.....
Condition welding.....				.....
Condition piston rod.....				.....
Condition of the covers.....				.....
Closeness of the hydraulic system.....				.....
Level of hydraulic oil.....				.....
Condition hydraulic hoses.....				.....
Condition electrical wires.....				.....
Function test with vehicle.....				.....
Function equalisation of the rails.....				.....
Function CE-Stop.....				.....
Condition Polymer supports.....				.....
Function test wheel free lift (with vehicle).....				.....
Function lightning.....				.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....  
(Use another form for verification!) .....  
signature of the operator


### **Manual service operation over the keyboard**

*Activity only for authorized persons.*

One foil-keyboard and one LC-Display for the position-information and the service-operation are integrated in the control-box/operating unit.

#### **1. After turning on the power, the following information appears on the display .**

After 5 seconds, one switches automatically to the position-information 2.



#### **2. Position-information**

Ad the position of the 2 axes during the normal operation of the lift.

A1-A2: position-value of the 2 axes

A1: 0.0
A2: 0.0
MP1 MP2 MP3

Step during the business a mistake on, the axis becomes with the mistake through „-E - „, in the position-information marked.

The information changes between the position-information and the error message.

Only when a such mistake was caused, should after telephonic consultation with the Nussbaum Company, phone, 0049 (0)7853-899-0, the service-functions, (sees section 4 (service-operating) become used.  
With full function-willingness of the automotive-lift, the operating of the service - functions, over the foil-keyboard is forbidden.

Examples:

information statuses with synchronism-mistake of axis 1

A1: 50.3 -E-
A2: 0.0

F e h l e r  
Gleichlauf

*Function button:*

- < \* > Change into the time indicator (3)
- < # > change to the service function (4)
- < 1 > switch "on/off" the measure point 1
- < 2 > switch "on/off" the measure point 2
- < 3 > switch "on/off" the measure point 3

### 3. Elapsed time indicator-information

The number of the working hours can be extract through the operating. Press the button < \* > on the foil-keyboard of the lift.

Information of the working hours in hours: minute  
Only the time is counted, in which the lift  
actually drives.

Betriebsstunden  
0000000:00 h

The return to the position-information takes place automatically anuses approximately 15 seconds or through operates of the < \* > -button.

*Function button:*

- < \* > Return to the position-information (2).

### 4. Service-operation

The service operation is used for it, during the initiation (installation) or to do the lift after a disturbance in function again. Only for these two cases, this operating mode of the lift is intended. Is not allowed to activate these functions, if the lift has the normal function. The functions of the service operation can be activated over the foil-keyboard appropriate on the switchbox. To the navigation in the menu system of the service functions serves the buttons:

<\*> **menu-point**  
< #>**confirms the menu-point**

Through presses and confirming " zurück " you can go back from a submenu into the higher ranking menu again.

#### 4.1 Log-in in the service-operation

The operator must log-in in the service-operation to activate the service-functions. He presses during the position-information the button # and inputs afterwards SERVICE-PIN. After correct input the PIN takes place automatically the change into the service-main menu.

Passwort

- - - -

Retrieval of the password for service-functions

Default-value of the password is ' 1234 '.

This can be altered with demand over the PC-Software, the new password is secured durably with it in the FRAM of the „Achscontrollers“.

*Function button:*

<\*> Back to the position-information (2).

<0> ... < 9 > password input

## 4.2 Service-Menu

Dialed menu-point becomes through >< marked

>Gesteuert<  
Achse nullen  
Hubhöhe  
zurück

*Function button:*

< \* > next menu-point dials

< #> menu-point activates

The menu-point becomes >zurück < activated jumps back this to the position-information.

## 4.3 STEERED

Both axes of the lift can be driven individually over the function " GESTEUERT ". The driven axis becomes over “\*“ marks and demarcates and after it over „#“ activates. This function can be used only in the disturbance-case!  
controlled operation - axis 1 active

\*1\* 50.3  
2 0.0

The controlled business over the information-functions is only possible if the dip-switch stands 5 on the “Achscontroller” on “ON”!

If the dip-switch 5 is standing on “OFF”, the axe drives over the dip-switch-attitude, independently from the information-function.

Over the buttons < 1 >, < 2 > is dialed the axes, the steered procedures should become.  
The dialed axes become on the ad through \*X \* marks.

If the button < lifting > or < lowering > was pressed afterwards, only the select axe can moved.

**! The installation can become destroyed.**

*Function button:*

< \* > Abortion and return into the service-menu (4.2)

< 1 > axe 1 activates / deactivates  
< 2 > axe 2 activates / deactivates

#### **4.4 Reset of the measuring systems**

Over this function, the entire measuring-system of the lift can be put back, (zero). This function is allowed to only after consultation with the service-headquarters of the Nussbaum Company (phone) + 49 (0)7853-899-0.

**Achse nullen?**

Alert message, whether axes should really become reset.

With confirmation of the retrieval with < #> is put down the axes on zero and is jumped back automatically to the position-information (2) afterwards.

That zeros of the axes is only possible, if the dip-switch 5 on the „Achscontroller“ stands on „ON“.

**! The installation can become destroyed.**

*Function button:*

< \* > Abortion and return into the service-menu (4.2)  
< #> axes becomes on zero favored

#### **4.5 Altitudes restricts**

The maximum lifting of the lift can be restricted over the menu-point " HUBHOEHE ". The indicated value can over the button < 1 > increment and over the button < 0 > decrement becomes. After election of the desired lift, becomes over < #> the value taken on. The submenu was deserted.

The submenu was deserted with the button and the changed value was not stored.

*Function button:*

< \* > **Demolition and return into the service-menu without stores**  
< #> store the new value and return into the service-menu  
< 1 > Increases the lifting height  
< 0 > Reduces the lifting height


#### **4.6 going back**

From a submenu, one can come back into the paramount menu again. Press the button "ZURÜCK".



## Hydraulic diagram without wheel free lift

**Block,kpl. UNI-LIFT - CLT**  
**99 529 04 00 5**  
**SN: 158662**




H-Plan UNI CLT 11-01.jpg  
26.11.01

**Hydraulic parts list**

<b>Nr.</b>	<b>description</b>	<b>order number</b>
0.1	oil tank	
0.2	oil filter	980012
0.3	gear pump	9750510112304
0.4	sub oil motor	990445
0.5	oil level gauge	980098
0.6	holding valve	980166
0.7	hydraulic bloc complete	99 529 04 005
0.8	hydraulic block	06-605A-01-01
DB1	pressure relief valve	155211
DB2	pressure relief valve (unlocking cylinder)	155211
M1-M4	measuring connection	155470
VW1	proportional valve	WEP06DA01B0240S
VW2	proportional valve	WEP06DA01B0240S
VW3	4/2-way-valve	WE06DA77A0240X
V1	electric unlockable holding valve	980338
N1	emergency lowering screw	120026
N2	emergency lowering screw	120026
SV1	double seat valve	980853
SV2	double seat valve	980853
1.0	cylinder of the lift	
2.0	unlocking cylinder of the lift	

## Hydraulic diagram with wheel free lift 0.25 CLT

**Block,kpl. UNI-LIFT CLT plus**  
**99 529 03 00 5**  
**SN: 158661**




H-Plan UNI CLT-CLT11-01.jpg  
26.11.01

**Hydraulic parts list**

<b>Nr.</b>	<b>description</b>	<b>order number</b>
0.1	oil tank	
0.2	oil filter	980012
0.3	gear pump	9750510112304
0.4	sub oil motor	990445
0.5	oil level gauge	980098
0.6	holding value	980166
0.7	hydraulic bloc complete	99 529 03 005
0.8	hydraulic block	06-605A-01-01
DB1	pressure relief valve	155211
DB2	pressure relief valve (unlocking cylinder)	155211
M1-M4	measuring connection	155470
VW1	proportional valve	WEP06DA01B0240
VW2	proportional valve	WEP06DA01B0240
VW3	4/2-way valve	WE06DA77A0240X
V1	electric unlockable holding valve	980338
N1	emergency lowering screw	120026
N2	emergency lowering screw	120026
SV1	double seat valve	980853
SV2	double seat valve	980853
SV3	double seat valve	980853
SV4	double seat valve	980853
1.0	cylinder of the lift	
2.0	unlocking cylinder of the lift	
3.0	cylinder of the wheel free lift	

## Electric diagram without wheel free lift



SCHALTPLAN

VERGNDUNG DACH ÖRTLICHEN VERSCHRIFFEN

- Vor Inbetriebnahme prüfen, ob Motorenstrom mit Motorschutzrelais übereinstimmt. Alle Klemmstellen auf Ordnungsgemäße Verbindung und alle Kontaktschrauben auf festen Sitz prüfen.
- Vor Inbetriebnahme Verdrahtung und Steuerung auf richtige Funktion überprüfen. Keine Inbetriebnahme von unbefugter Seite vornehmen lassen Änderungen vorbehalten

SCHALTBAEDE UND SCHALTGERÄTE

## 2.1 Funktionsprüfung der Schaltanlagen


Diese Pläne sind auf einem CAD-System erstellt worden um die Pläne immer auf dem aktuellen Stand zu halten. Känderungen nur durch uns vornehmen zu lassen.


Diese Schaltpläne sind unser geistiges Eigentum.  
Sie dürfen ohne unsere Genehmigung weder ver-  
vielfältigt noch Dritten weitergegeben werden!





ÄNDERUNGS-INFORMATIONEN			
Nr.	Datum	Firma	Bearbeiter
Änderungen			
0			
1			
2			
3			
4			
5			
6			
7			
8			
9			
3			

2	 Nussbaum Hebelechnik GmbH & Co. KG Tel.: 0391/632893-0 Fax.: 0391/632898 E-Mail: <a href="mailto:nus01@nus3.nus.de">nus01@nus3.nus.de</a>			Unilift CLT	Unilift CLT 01/03/001	+
3	Änderung	Datum	Name	Urtyp	Ers. f.	Ers. d.







Datum		Datum		Datum		Datum		Datum		Datum	
Baard.	BME	Baard.	BME	Baard.	BME	Baard.	BME	Baard.	BME	Baard.	BME
Gepr.	20.10.2003	Gepr.									
Name		Name		Name		Name		Name		Name	
Unternehm.		Unternehm.		Unternehm.		Unternehm.		Unternehm.		Unternehm.	
Bürostandort		Bürostandort		Bürostandort		Bürostandort		Bürostandort		Bürostandort	

**Mussbaum**

Mussbaum Hebeutechnik GmbH & Co KG  
Freyerstraße 24  
D-8833 Böckingen  
Tel.: 089/8933955-0 Fax: 089/8933955-887

Urt. d.  
Erst: €  
Erz. = d

Unilift CLT


Unilift CLT 01/03/001


Unilift CLT

Unilift CLT 01/03/001

Unilift CLT

Unilift CLT







卷之三

UPRN020 / 22.04.1996

-eis tembezelchnung

KLemmenPlan

9

Unilift CLT 01/03/001				Unilift CLT 01/03/001			
Bearb.	Bez.	Datum	Gepr.	Bearb.	Bez.	Datum	Gepr.
BRN	Nussbaum Hebelechnik GmbH & Co. KG Hoher Stein 24 1611 : 093 61 83935-8 Fax: 093 61 8327887	20.10.2003	BRN	BRN	Nussbaum Hebelechnik GmbH & Co. KG Hoher Stein 24 1611 : 093 61 83935-8 Fax: 093 61 8327887	20.10.2003	BRN
Ers. f.	Ers. d.			Ers. f.	Ers. d.		

1

6

2

**MUSSEBACH** Hussbaum Hebelechnik GmbH & Co. KG  
Tel.: +49 9132/933-0 Fax: +49 9132/933-888  
Ers. d. Urspr.

Bauteilbezeichnung Component design.		Menge Amount	Bezeichnung Designation	Typennummer Model number	Lieferant Supplier	Artikelnummer Article number			
0	1	2	3	4	5	6	7	8	9
NUSTÜCK 1 17. 01. 2003									
P1	1		Rechnercontroller PSC 4000 Vollversion	910260	IPV GmbH	910260			
R1			Feste Platine GPS für Rechnercontroller	FEDERLEISTE 6-polig	Keller GmbH	911416			
P1	35		Flanschtechnik 2.8	43101213 204	Plüschhülsen	911352			
P1	35		Isolierstühle 2.8	F 2.8	Plüschhülsen	911353			
P2	1		Foienmaschine für PSC 4000	113-91503	RS Compo	910255			
R2	1		Tastaturlkabel Rechnercontroller	91027-3	IPV GmbH	911353			
R3	1		Display für PSC 4000	DEH16941 SY-L-Y/L	Display Elektronik GmbH	910257			
P3	1		Displaylabel Rechnercontroller	91027-4	IPV GmbH	910270			
P3	1		Displayrahmen groß mit Tastatur	91029-0	Gronau	910630			
B1			HALLENELEKTRONIKSCHALTER	HOD-1616500L 5-55001/5	Kalaschka GmbH	911635			
B2	1		HALLENELEKTRONIKSCHALTER	HOD-1616500L 5-55001/5	Kalaschka GmbH	910639			
E1	1		2 * Stabblaulampe 1m Klemmkasten		Nussbaum	0310302			
E3	1		2 m Stabblaulampe 1m Klemmkasten		Nussbaum	0310302			
F1	1		Sicherungsdeckel kleine Trenner 5x20 mm	Hu/8. SF	Entrelac	910161			
F1	1		Feinsicherung	FEINSICHERUNG	GF	910175			
F2	1		Sicherungsdeckel kleine Trenner 5x20 mm	Hu/8. SF	Entrelac	910161			
F2	1		Feinsicherung	FEINSICHERUNG	GF	910166			
F3	1		Sicherungsdeckel kleine Trenner 5x20 mm	Hu/8. SF	Entrelac	910161			
F3	1		Feinsicherung	FEINSICHERUNG	GF	910167			
F4	1		Sicherungsdeckel kleine Trenner 5x20 mm	Hu/8. SF	Entrelac	910161			
F4	1		Feinsicherung	FEINSICHERUNG	GF	910166			
F5	1		Sicherungsdeckel kleine Trenner 5x20 mm	Hu/8. SF	Entrelac	910161			
F5	1		Feinsicherung	FEINSICHERUNG	GF	910166			
F6	1		Sicherungsdeckel kleine Trenner 5x20 mm	Hu/8. SF	Entrelac	910161			
F6	1		Feinsicherung	FEINSICHERUNG	GF	910167			
G1	1		+ Dünnschichtrichter +Kontaktsensor	TRAFD-1-FH	Schmidler	910155			
G2	1		Schalt-Netzgerät DC 24 V /2.5A	SEB-F-24	Peukert	910101			
H1	1		Diodenkondensator akustischer Signaleiter	B/P 228	Daltron Components	910131			
KH1	1		Leistungsschutz 5.7 kW 24V DC	11B612.01 0 24V DC		910142			
H1	1		Unterpolmotor 3kW/6.5A 50Hz 100V 2750min-1	0.05/T-0.020-0V/50		910145			
H1	1		Hauptrisch. Mot.-pus 3p 16P 5.5kW	H 105/3-020-0V/50	Herz GmbH	910103			
S1	1		Kahlkasten 2st. Drehn. I. 0 rest. (Hu22)	H42-WR	Hoeller	910146			
S1	1		Kontaktklock 1S (Hu22)	H42-XK10	Hoeller	910142			
S2	1		Druckplatte Flach o. Fest. Platte (Hu22)	H42-01-X	Hoeller	910130			
S2	1		Fastenplatte Flach 1S (Hu22)	H42-X-0-S-X?	Hoeller	910131			
S2	1		Kontaktklock 1S (Hu22)	H42-X-K11	Hoeller	910132			
S2	1		Kontaktelement 1S (Hu22)	H42-K10	Hoeller	910133			
S3	1		Druckplatte Flach o. Fest. Platte (Hu22)	H42-01-X	Hoeller	910130			
S3	1		Fastenplatte Flach 1S (Hu22)	H42-X-0-S-X?	Hoeller	910131			
S3	1		Kontaktklock 1S (Hu22)	H42-X-K11	Hoeller	910132			
S3	1		Kontaktelement 1S (Hu22)	H42-K10	Hoeller	910133			
S4	1		Druckplatte Flach o. Fest. Platte (Hu22)	H42-01-X	Hoeller	910130			
S4	1		Kontaktklock 1S (Hu22)	H42-X-0-S-X?	Hoeller	910131			
S4	1		Kontaktelement 1S (Hu22)	H42-X-K10	Hoeller	910132			
S5	1		Druckplatte Flach o. Fest. Platte (Hu22)	H42-X-0-S-X?	Hoeller	910131			
S5	1		Kontaktklock 1S (Hu22)	H42-X-K11	Hoeller	910132			
S5	1		Kontaktelement 1S (Hu22)	H42-K10	Hoeller	910133			
S5	1		Druckplatte Flach o. Fest. Platte (Hu22)	H42-01-X	Hoeller	910130			
V1	1		Spannperiode BiV 28-100 1000U/38	BIV 28 -100	Conrad Elektronik	910142			
V2	1		Spannperiode 3kW007 1000V:18	1 N 4000/7	Conrad Elektronik	910152			
X1	1		Schutzleiterklemme 2.5/8 P. ADD schraub-schn	DR 2.5/8 P. ADD	Entrelac	910679			
X1	1		Schutzleiterklemme 0.1-5/6 P. ADD schraub-schn	0.1-5/6 P. ADD	Entrelac	910578			
X1	1		Reihenklemme 0.1-5/6 N. ADD d1 schraub-schn	0.1-5/6 N. ADD	Entrelac	910577			



Nussbaum Hebeetechnik GmbH & Co. KG  
Küller Straße 20  
78574 Konz (Rheinland-Pfalz)  
Tel.: +49 (0)7533-0 1000-0  
Fax: +49 (0)7533-0 1000-1000  
E-mail: info@nussbaum.de

Nussbaum Hebeetechnik GmbH & Co. KG  
Küller Straße 20  
78574 Konz (Rheinland-Pfalz)  
Tel.: +49 (0)7533-0 1000-0  
Fax: +49 (0)7533-0 1000-1000  
E-mail: info@nussbaum.de

## Stückliste Bill of materials

Bauteilbezeichnung Component design.	Menge Amount	Bezeichnung Designation	Typen number Model number	Lieferant Supplier	Artikelnummer Article number
X1	13	Reihenklammer OR 1.5/6.000 sch-n-schn	OR 1.5/6.000	Entelac	930702
X2	13	Reihenklammer OR 1.5/6.000 sch-n-schn	OR 1.5/6.000	Entelac	930702
X2	2	Schutzlinse OR 2.5/8. P.000 schn-schn	OR 2.5/8. P.000	Entelac	930673
XB1	1	Buchsenhalze 4 polig ku	2.105.50.230.050	Börsig GmbH	930407
XB1	1	Steckereinhäuse 4 polig ku	2.105.50.230.051	Börsig GmbH	930408
XB1	3	Flachstichhülse Buchse 6.3mm	05497.12.111	Puplichthausen	930138
XB1	3	Flachstichhülse Buchse 6.3mm	08632.12.211	Puplichthausen	930129
XB2	3	Flachstichhülse Stecker 6.3mm	05497.12.111	Puplichthausen	930128
XB2	3	Flachstichhülse Buchse 6.3mm	08632.12.211	Puplichthausen	930129
XB2	1	Buchsenhäuse 4 polig ku	2.105.50.230.050	Börsig GmbH	930407
XB2	1	Steckereinhäuse 4 polig ku	2.105.50.230.051	Börsig GmbH	930408
XH1	1	Stiftsatz für Gerätestecker	STIFTEIN SITZ	Spörle GmbH	931310
XH1	1	Buchseninssatz für Gerätestecker	BUCHSENEINSITZ	Spörle GmbH	931311
XH1	6	Steckverb. Gerätestecker ku 6 pol.	STECKERBLÄNDER	Spörle GmbH	930918
XH1	6	Steckverb. Gerätestecker ku 6 pol.	STECKERBLÄNDER	BS Component	930919
XH2	1	Stiftsatz für Gerätestecker	STIFTEIN SITZ	Spörle GmbH	931310
XH2	1	Buchseninssatz für Gerätestecker	BUCHSENEINSITZ	Spörle GmbH	931311
XH2	6	Steckverb. Gerätestecker ku 6 pol.	STECKERBLÄNDER	Spörle GmbH	930918
XH2	6	Steckverb. Gerätestecker ku 6 pol.	STECKERBLÄNDER	BS Component	930919
XSP	3	Flachstichhülse Stecker 6.3mm	05497.12.3.111	Puplichthausen	930129
XSP	3	Flachstichhülse Buchse 6.3mm	08632.12.3.211	Puplichthausen	930129
XSP	1	Buchsenhäuse 4 polig ku	2.105.50.230.050	Börsig GmbH	930407
XSP	1	Steckereinhäuse 4 polig ku	2.105.50.230.051	Börsig GmbH	930408
XST	3	Flachstichhülse Stecker 6.3mm	05497.12.3.111	Puplichthausen	930128
XST	3	Flachstichhülse Buchse 6.3mm	08632.12.3.211	Puplichthausen	930129
XST	1	Buchsenhäuse 4 polig ku	2.105.50.230.050	Börsig GmbH	930407
XST	1	Steckereinhäuse 4 polig ku	2.105.50.230.051	Börsig GmbH	930408

12

## Electric diagram with wheel free lift

	<b>SCHALTPLAN</b>	
<b>Nussbaum Hebetechnik</b> GmbH & Co. KG Korker Straße 24 D-77694 Kehl Bodersweier Tel.: +49(0)7853/899-0	<b>OBJEKT</b> : Unilift CLT Plus <b>ANLAGE</b> : <b>KUNDE</b> : <b>SCHALTPLANNR:</b> Unilift CLT Plus 01/03/001	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200 201 202 203 204 205 206 207 208 209 210 211 212 213 214 215 216 217 218 219 220 221 222 223 224 225 226 227 228 229 230 231 232 233 234 235 236 237 238 239 240 241 242 243 244 245 246 247 248 249 250 251 252 253 254 255 256 257 258 259 260 261 262 263 264 265 266 267 268 269 270 271 272 273 274 275 276 277 278 279 280 281 282 283 284 285 286 287 288 289 290 291 292 293 294 295 296 297 298 299 300 301 302 303 304 305 306 307 308 309 310 311 312 313 314 315 316 317 318 319 320 321 322 323 324 325 326 327 328 329 330 331 332 333 334 335 336 337 338 339 340 341 342 343 344 345 346 347 348 349 350 351 352 353 354 355 356 357 358 359 360 361 362 363 364 365 366 367 368 369 370 371 372 373 374 375 376 377 378 379 380 381 382 383 384 385 386 387 388 389 390 391 392 393 394 395 396 397 398 399 400 401 402 403 404 405 406 407 408 409 410 411 412 413 414 415 416 417 418 419 420 421 422 423 424 425 426 427 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462 463 464 465 466 467 468 469 470 471 472 473 474 475 476 477 478 479 480 481 482 483 484 485 486 487 488 489 490 491 492 493 494 495 496 497 498 499 500 501 502 503 504 505 506 507 508 509 510 511 512 513 514 515 516 517 518 519 520 521 522 523 524 525 526 527 528 529 530 531 532 533 534 535 536 537 538 539 540 541 542 543 544 545 546 547 548 549 550 551 552 553 554 555 556 557 558 559 550 551 552 553 554 555 556 557 558 559 560 561 562 563 564 565 566 567 568 569 560 561 562 563 564 565 566 567 568 569 570 571 572 573 574 575 576 577 578 579 580 581 582 583 584 585 586 587 588 589 590 591 592 593 594 595 596 597 598 599 600 601 602 603 604 605 606 607 608 609 610 611 612 613 614 615 616 617 618 619 620 621 622 623 624 625 626 627 628 629 630 631 632 633 634 635 636 637 638 639 640 641 642 643 644 645 646 647 648 649 650 651 652 653 654 655 656 657 658 659 660 661 662 663 664 665 666 667 668 669 670 671 672 673 674 675 676 677 678 679 680 681 682 683 684 685 686 687 688 689 690 691 692 693 694 695 696 697 698 699 700 701 702 703 704 705 706 707 708 709 7010 7011 7012 7013 7014 7015 7016 7017 7018 7019 7020 7021 7022 7023 7024 7025 7026 7027 7028 7029 7030 7031 7032 7033 7034 7035 7036 7037 7038 7039 7040 7041 7042 7043 7044 7045 7046 7047 7048 7049 7050 7051 7052 7053 7054 7055 7056 7057 7058 7059 7060 7061 7062 7063 7064 7065 7066 7067 7068 7069 7070 7071 7072 7073 7074 7075 7076 7077 7078 7079 7080 7081 7082 7083 7084 7085 7086 7087 7088 7089 7090 7091 7092 7093 7094 7095 7096 7097 7098 7099 70100 70101 70102 70103 70104 70105 70106 70107 70108 70109 70110 70111 70112 70113 70114 70115 70116 70117 70118 70119 70120 70121 70122 70123 70124 70125 70126 70127 70128 70129 70130 70131 70132 70133 70134 70135 70136 70137 70138 70139 70140 70141 70142 70143 70144 70145 70146 70147 70148 70149 70150 70151 70152 70153 70154 70155 70156 70157 70158 70159 70160 70161 70162 70163 70164 70165 70166 70167 70168 70169 70170 70171 70172 70173 70174 70175 70176 70177 70178 70179 70180 70181 70182 70183 70184 70185 70186 70187 70188 70189 70190 70191 70192 70193 70194 70195 70196 70197 70198 70199 70200 70201 70202 70203 70204 70205 70206 70207 70208 70209 70210 70211 70212 70213 70214 70215 70216 70217 70218 70219 70220 70221 70222 70223 70224 70225 70226 70227 70228 70229 70230 70231 70232 70233 70234 70235 70236 70237 70238 70239 70240 70241 70242 70243 70244 70245 70246 70247 70248 70249 70250 70251 70252 70253 70254 70255 70256 70257 70258 70259 70260 70261 70262 70263 70264 70265 70266 70267 70268 70269 70270 70271 70272 70273 70274 70275 70276 70277 70278 70279 70280 70281 70282 70283 70284 70285 70286 70287 70288 70289 70290 70291 70292 70293 70294 70295 70296 70297 70298 70299 70300 70301 70302 70303 70304 70305 70306 70307 70308 70309 70310 70311 70312 70313 70314 70315 70316 70317 70318 70319 70320 70321 70322 70323 70324 70325 70326 70327 70328 70329 70330 70331 70332 70333 70334 70335 70336 70337 70338 70339 70340 70341 70342 70343 70344 70345 70346 70347 70348 70349 70350 70351 70352 70353 70354 70355 70356 70357 70358 70359 70360 70361 70362 70363 70364 70365 70366 70367 70368 70369 70370 70371 70372 70373 70374 70375 70376 70377 70378 70379 70380 70381 70382 70383 70384 70385 70386 70387 70388 70389 70390 70391 70392 70393 70394 70395 70396 70397 70398 70399 70400 70401 70402 70403 70404 70405 70406 70407 70408 70409 70410 70411 70412 70413 70414 70415 70416 70417 70418 70419 70420 70421 70422 70423 70424 70425 70426 70427 70428 70429 70430 70431 70432 70433 70434 70435 70436 70437 70438 70439 70440 70441 70442 70443 70444 70445 70446 70447 70448 70449 70450 70451 70452 70453 70454 70455 70456 70457 70458 70459 70460 70461 70462 70463 70464 70465 70466 70467 70468 70469 70470 70471 70472 70473 70474 70475 70476 70477 70478 70479 70480 70481 70482 70483 70484 70485 70486 70487 70488 70489 70490 70491 70492 70493 70494 70495 70496 70497 70498 70499 70500 70501 70502 70503 70504 70505 70506 70507 70508 70509 70510 70511 70512 70513 70514 70515 70516 70517 70518 70519 70520 70521 70522 70523 70524 70525 70526 70527 70528 70529 70530 70531 70532 70533 70534 70535 70536 70537 70538 70539 70540 70541 70542 70543 70544 70545 70546 70547 70548 70549 70550 70551 70552 70553 70554 70555 70556 70557 70558 70559 70560 70561 70562 70563 70564 70565 70566 70567 70568 70569 70570 70571 70572 70573 70574 70575 70576 70577 70578 70579 70580 70581 70582 70583 70584 70585 70586 70587 70588 70589 70590 70591 70592 70593 70594 70595 70596 70597 70598 70599 70600 70601 70602 70603 70604 70605 70606 70607 70608 70609 70610 70611 70612 70613 70614 70615 70616 70617 70618 70619 70620 70621 70622 70623 70624 70625 70626 70627 70628 70629 70630 70631 70632 70633 70634 70635 70636 70637 70638 70639 70640 70641 70642 70643 70644 70645 70646 70647 70648 70649 70650 70651 70652 70653 70654 70655 70656 70657 70658 

Inhaltsverzeichnis

Seite	Seitenbenennung	Seitentzusatzfeld		Spalte X: eine automatisch erzeugte Seite wurde manuell nachbearbeitet	KUPJ030 24.02.1994
		Datum	Bearbeiter	X	
1	Deckblatt	28.06.2002	BOE		
2	Inhaltsverzeichnis	17.01.2003	BOE		
3	Änderung	28.06.2002	BOE		
4	Einspeisung	17.01.2003	BOE		
5	Steuerspannung	17.01.2003	BOE		
6	Bedientasten	17.01.2003	BOE		
7	Achscontroller	17.01.2003	BOE		
8	Ventile	17.01.2003	BOE		
9	frei	17.01.2003	BOE		
10	X1 Steuerung	17.01.2003	BOE		
11	X2 Bedienung	17.01.2003	BOE		
12	Stückliste	17.01.2003	BOE		
13	Stückliste	17.01.2003	BOE		
14	Stückliste	17.01.2003	BOE		

Snaltes X: eine automatisch erzeugte Seite wurde manuell nachbearbeitet

KUPEJ 02021994

三

U

1


三


1


Nussbaum Hebelechnik GmbH & Co. KG Körver Straße 24 461 - 8777 Krefeld - Badische Str. 149 D-47839 Krefeld - Tel.: (02151) 7777		Unilift CLT Plus		Inhaltsverzeichnis	
		Datum	Bearb.	Erf. f.	Erf. d.
		Name	Name		
		20.10.2003			


ÄNDERUNGS-INFORMATIONEN				
Nr.	Datum	Firma	Bearbeiter	Änderungen
0				
1				
2				
3				
4				
5				
6				
7				
8				
9				
3				


2	Datum	Nussbaum Hebelelektronik GmbH & Co. KG D-7854 Kehl - Industriestrasse 2 Tel.: +49(0)7832/939-0 Fax: +49(0)7832/939-100	Unilift CLT Plus	-
3	Änderung	Name	Ers. d.	Bl.
4	Änderung	Name	Ers. d.	Bl.











0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 3

8		Datum	Nussbaum Hebeutechnik GmbH & Co. KG Wernerstraße 21 D-7735 Kehl - Badische Tel.: 07831/9393-0 Fax: 07831/9393-99 E-mail: info@nussbaum.de	Unilift CLT Plus	Free	+	10
		Betrieb	BUE				
		Geor.	20.10.2003				

9	Enderung	Datum	Name	Norm	Urspr.	Ers. f.	fr ei	81.
								14.81

卷之三

UPRN020 / 22.04.1996

## Teilsteinbezeichnung

1

Kabeltyp		Kabeltyp	
Anschluß	Ziel- bezeichnung	Anschluß	Ziel- bezeichnung
Klemmen- Symbol	Klemmen- nummer	Klemmen- Symbol	Klemmen- nummer
Briicken		Briicken	
G1	N	G1	N
M1	PE	X5T	2
X2	1	X2	1
R1	26	R1	26
X2	3	X2	3
R1	28	R1	28
X2	4	X2	4
R1 Z10	4	V1	1
X2	5	V1	5
R1 Z14	6	R1 Z14	6
X2	6	X2	6
R1 Z16	7	R1 Z16	7
X2	7	X2	7
Y5Z R1	9	Y5Z R1	9
X2	9	X2	9
R1 B22	10	Y5Z1 R1	11
X5	10	R1 B22	11
R1 B22	11	Y5Z1 R1	12
X5	11	R1 B22	12
KM1	R2	KM1	R2
X2	13	X2	13
Y5Z1 R2	14	Y5Z1 R2	14
X2	15	X2	15
Y5W1 R2	16	H1	2
X2	16	H1	2
R1	220	H1	17
X2	220	R1	220
R1	220	H1	1
X2	220	R1	220
Y5W1 R2	17	PE	PE
X2	220	PE	PE
G1	PE	G1	PE
X2	220	X2	220
Funktionsstabilität		Funktionsstabilität	
abheben Bühne		abheben Bühne	
senken Bühne		senken Bühne	
rutschen Bühne		rutschen Bühne	
aufheben Bühne		aufheben Bühne	
unterpol Motor		unterpol Motor	
zitzvential Multilay		zitzvential Multilay	
sägevential Multilay		sägevential Multilay	
UPC		UPC	

		Datum	Bearb.	BUK		Nussbaum Hebelelemente GmbH & Co. KG Haus der Gewerbe- und Dienstleistung Büro 200 - Badestraße Tel.: +49 (0) 89 30 935-0 Fax: +49 (0) 89 30 935-888	Unilift CLT Plus	X1 Steuerung	*

卷之三

NUPR020 / 22.04.1996

Lets tēnba zətchunung

2x2

Kabelname

1

104

104

1

2

1

1

6

1

1

1

be at


6

6

Stückliste Bill of materials						
Bauartbezeichnung Component design		Menge Amount	Bezeichnung Designation	Typennummer Model number	Lieferant Supplier	Artikelnummer Article number
P1	1		Rechteckcontroller PSC 4000 Vollversion	910.260	IVP GmbH	340.260
P1	1		Faderstecke 4pol für Rechteckcontroller	943.651-123.204	Höller GmbH	391.116
P1	15		Flachstecku. 2.8	F 2.8	Pudishhussen	391.152
P1	35		Isolierteile 2.8		Pudishhussen	393.353
P2	1		Fassatutatur für PSC 4000	113.350.3	IVP GmbH	390.165
P2	1		Fassatutatur für PSC 4000	930.875	DSI Components	390.165
P3	1		Display für PSC 4000	DEH-16481 SY-LY/L	IVP GmbH	390.527
P3	1		Displaykabel Rechteckcontroller	910.974	Dissilly Elektronik GmbH	390.527
P3	1		Displayrahmen grün. mit Tastatur	930.630	Grönau	390.930
P4	1		HALTELEMENTSHALTER	HOD-16HS00L 5-55N03/5	Kalschka GmbH	390.059
P2	1		HALTELEMENTSHALTER	HOD-16HS00L 5-55N03/5	Kalschka GmbH	390.059
P4	1		HALTELEMENTSHALTER	HOD-16HS00L 5-55N03/5	Kalschka GmbH	390.059
E1	1		2 x Stablauchste. 1x Klemmaste		Nussbaum	03.001.010.012
E3	1		2 x Stablauchste. 1x Klemmaste		Nussbaum	03.001.010.012
F1	1		Sicherungsstahle Träger 5x20 mm	M1/8 SF	Enteltec	390.061
F1	1		Fainsicherung		GIF	390.075
F2	1		Sicherungsstahle Träger 5x20 mm	M1/8 SF	Enteltec	390.061
F2	1		Fainsicherung		GIF	390.086
F3	1		Sicherungsstahle Träger 5x20 mm	M1/8 SF	Enteltec	390.061
F3	1		Fainsicherung		GIF	390.097
F4	1		Sicherungsstahle Träger 5x20 mm	M1/8 SF	Enteltec	390.061
F4	1		Fainsicherung		GIF	390.086
F5	1		Sicherungsstahle Träger 5x20 mm	M1/8 SF	Enteltec	390.061
F5	1		Fainsicherung		GIF	390.024
F6	1		Sicherungsstahle Träger 5x20 mm	M1/8 SF	Enteltec	390.062
F6	1		Fainsicherung		GIF	390.045
G1	1		Fainsicherung		Schneider	390.035
G2	1		+ Gleichrichter +ondensator	TIR-FU-1-PH	Reuton	390.101
G3	1		Schalt-Nettgrät DC 24 V 2.5A	SEU-FU-24	Deutron Components	390.131
H1	1		Diodenord akustischer Signalleiter	B/P 2.28		
KM1	1		Leistungsdreh. 5.7 kW 24 V DC	118.852.01.0 24V DC		
H1	1		Untergrätmat 3kW/6.8kW 50Hz 400V 720main-1	0.25/1		
H1	1		Hauptsch. Not-Bus 30.16P 5.8kW	R 105/3-0200-E/50	Herz GmbH	390.003
S1	1		Wählkiste 25t. Drehkn. 1.0 rast. (H22)	H22-WR	Höller	390.046
S1	1		Kontaktblock 15 (H22)	H22-RK10	Höller	390.142
S2	1		Drucktaste flach o. fast Platte (H22)	H22-DTL-X	Höller	390.370
S2	1		Drucktaste flach o. fast Platte (H22)	H22-X-0.5-X?	Höller	390.370
S2	1		Kontaktblock 15 (H22)	H22-RK11	Höller	390.132
S2	1		Kontaktelement 15 (H22)	H22-K10	Höller	390.133
S2	1		Kontaktelement 10 (H22)	H22-K01	Höller	390.181
S3	1		Kontaktelement 10 (H22)	H22-DL-X	Höller	390.130
S3	1		Drucktaste flach o. fast Platte (H22)	H22-X-0.5-X?	Höller	390.133
S3	1		Drucktaste flach o. fast Platte (H22)	H22-RK11	Höller	390.132
S3	1		Kontaktelement 15 (H22)	H22-K10	Höller	390.133
S3	1		Kontaktelement 10 (H22)	H22-K01	Höller	390.181
S4	1		Drucktaste flach o. fast Platte (H22)	H22-DL-X	Höller	390.130
S4	1		Drucktaste flach o. fast Platte (H22)	H22-RK10	Höller	390.142
S5	1		Kontaktelement 15 (H22)	H22-X-0.5-X?	Höller	390.133
S5	1		Drucktaster Einbau klein 15	05.131	DEUTEM	390.066
S6	1		Drucktaste flach o. fast Platte (H22)	H22-DL-X	Höller	390.130

0	1	2	3	4	5	6	7	8	9
---	---	---	---	---	---	---	---	---	---

## Stückliste Bill of materials

HUSTUKI 17. 01. 2003

Bauteilbezeichnung Component design.	Menge Amount	Bezeichnung Designation	Typennummer Model number	Lieferant Supplier	Artikelnummer Article number
S6	1	Tastenplatte Pfeil 1 (H22)	H22-205-S-X7	Moeller	390131
S6	1	Kontaktklotz 15/10 (H22)	H22-HK11	Moeller	390132
S6	1	Kontaktelement 15 (H22)	H22-K10	Moeller	390133
S7	1	Drucktaste flach o Tast Platte (H22)	H22-011-X	Moeller	390134
S7	1	Tastenplatte Pfeil 2 (H22)	H22-205-S-X7	Moeller	390130
S7	1	Kontaktklotz 15 (H22)	H22-HK11	Moeller	390131
S7	1	Kontaktelement 15 (H22)	H22-K10	Moeller	390132
V1	1	Spannperiode BYV 29 -100 1000V..JP	BYV 29 -100	Conrad Elektronik	390042
V2	1	Spannperiode JN4007 1000V..IR	1 N 40007	Conrad Elektronik	390052
V3	1	Spannperiode 1N4007 1000V..IR	1 N 40007	Conrad Elektronik	390052
V4	1	Spannperiode BYV 28 -100 1000V..JP	BYV 28 -100	Conrad Elektronik	390042
X1	1	Schutzsteckerk1 DR 2,5/8,-P.000 schraub-schn	DR 2,5/8,-P.000	Entrelac	390133
X1	1	Schutzsteckerk1 DR 1,5/6,-P.000 schraub-schn	DR 1,5/6,-P.000	Entrelac	390134
X1	1	Rohrenlampe Ø 1,5/6 N.000 b1 schraub-schn	Ø 1,5/6, N.000	Entrelac	390177
X1	17	Rohrenlampe ØR 1,5/6.000 schraub-schn	ØR 1,5/6.000	Entrelac	390172
X2	16	Rohrenlampe ØR 1,5/6.000 schraub-schn	ØR 1,5/6.000	Entrelac	390172
X2	2	Schutzsteckerk1 DR 2,5/8,-P.000 schraub-schn	DR 2,5/8,-P.000	Entrelac	390173
X01	1	Buchsengehäuse 4-polig ku	2 105 5029050	Börsig GmbH	390107
X01	1	Steckergehäuse 4-polig ku	2 105 5029051	Börsig GmbH	390108
X01	3	Flachsteckkhule Stecker 6..Jmm	05147 123 111	Publithausen	390123
X01	3	Flachsteckkhule Buchse 6..Jmm	08632 123 211	Publithausen	390123
X02	3	Flachsteckkhule Stecker 6..Jmm	05147 123 111	Publithausen	390123
X02	3	Flachsteckkhule Buchse 6..Jmm	08632 123 211	Publithausen	390123
X02	1	Buchsengehäuse 4-polig ku	2 105 5029050	Börsig GmbH	390107
X02	1	Steckergehäuse 4-polig ku	2 105 5029051	Börsig GmbH	390108
X01	1	Stiftleinsatz für Gerätestecker	STIFFEINSATZ	Spörle GmbH	391130
X01	1	Buchseleinsatz für Gerätestecker	BUCHSELEINSATZ	Spörle GmbH	391131
X01	6	Steckverb Gerätestecker ku 6 pol.	STECKERBINDER	Spörle GmbH	390119
X01	6	Steckverb Gerätestecker ku 6 pol.	STECKERBINDER	RS Component	390113
X02	1	Stiftleinsatz für Gerätestecker	STIFFEINSATZ	Spörle GmbH	391130
X02	1	Buchseleinsatz für Gerätestecker	BUCHSELEINSATZ	Spörle GmbH	391131
X02	6	Steckverb Gerätestecker ku 6 pol.	STECKERBINDER	Spörle GmbH	390119
X02	6	Steckverb Gerätestecker ku 6 pol.	STECKERBINDER	RS Component	390113
X02	6	Stiftleinsatz für Gerätestecker	STIFFEINSATZ	Spörle GmbH	391130
X04	1	Buchseleinsatz für Gerätestecker	BUCHSELEINSATZ	Spörle GmbH	391131
X04	6	Steckverb Gerätestecker ku 6 pol.	STECKERBINDER	Spörle GmbH	390119
X04	6	Stiftleinsatz für Gerätestecker ku 6 pol.	STIFFEINSATZ	Spörle GmbH	391130
X05	3	Flachsteckkhule Stecker 6..Jmm	05147 123 111	Publithausen	390123
X05	3	Flachsteckkhule Buchse 6..Jmm	08632 123 211	Publithausen	390123
X05	1	Buchsengehäuse 4-polig ku	2 105 5029050	Börsig GmbH	390107
X05	1	Steckergehäuse 4-polig ku	2 105 5029051	Börsig GmbH	390108
X05	3	Flachsteckkhule Stecker 6..Jmm	05147 123 111	Publithausen	390123
X05	3	Flachsteckkhule Buchse 6..Jmm	08632 123 211	Publithausen	390123

12

14

Bestell-Nr.	Datum	Datum	Bar.-Nr.	Bar.-Nr.	Unilift CLT Plus	+	-
Bestell-Nr.	Datum	Name	Norm	Urf. d.	Erf. f.	Erf. d.	Stückliste

13

14

<b>MUESSbaum</b>	Nussbaum Hebelechnik GmbH & Co. KG Haus der Götzenstrasse 24 D-8531 Bruckberg - Bautzen Tel.: 03522/911510 - Fax: 03522/911510		Unilift CLT Plus		Stückliste
	Datum	Bearb. BE	Gepr.	Fr.s.d.	
	01.10.2003			Ers.f.	
Änderung	Datum	Name Norm			

